Byron ™
Since 1904

2. PARTS DESCRIPTION

2.1 BOX CONTENT

1. Byron

2.

3.

4.

5.

6.

7. 6x 6x 1x

8.

2.2 INDOOR UNIT (MONITOR)

Byron

① ⑨ ⑩ ⑪

② ③ ④ ⑤ ⑥ ⑦ ⑧

2.3 OUTDOOR UNIT (DOORBELL)

① ② ③ ④ ⑤

3. INSTALLATION

3.1 FIX THE MOUNTING PLATE OF THE INDOOR UNIT (MONITOR)

A+B

C

D   2x

E+F

3.2 FIX THE MOUNTING PLATE OF THE OUTDOOR UNIT (DOORBELL)

A+B

C

D   4x

E

F

G

3.3 ELECTRICAL INSTALLATION

Indoor monitor

Byron

Outdoor camera

2 wire

2 wire   Door lock (not included)

2 wire

Power   Gate opener (not included)

Power DC 15V

3.3.1 CONNECTING THE INDOOR UNIT (MONITOR) TO THE OUTDOOR UNIT (DOORBELL)

Byron

Byron

Door lock (not included)

⊕ Power ⊖

Red

Black

Gate opener (not included)

### 3.3.2 CONNECTING THE AC ADAPTER

Byron

Power DC 15V

Indoor monitor

4. BASIC FUNCTIONS

3.3.3 MOUNT THE INDOOR UNIT AND OUTDOOR UNIT

A

B

3.3.4 CONNECTING A GATE OPENER (NOT INCLUDED)

Power

Gate opener
(not included)

Byron

3.3.5 CONNECTING A DOOR LOCK (NOT INCLUDED)

Byron

Door lock
(not included)

Byron

① ② ③ ④ ⑤ ⑥ ⑦

2. VOLUME CONTROL

A

OFF

hold
2
sec

B

OFF

− +

3. RINGTONE SETTINGS

A

OFF

hold
2
sec

B

OFF

♫ → ♫♪