2. PARTS DESCRIPTION

2.1 BOX CONTENT

1. 1x

2. 1x

3. 1x

4. 1x

5. 1x

6. 1x

7. 6x 6x 1x

8. 1x

2.2 INDOOR UNIT (MONITOR)

① ② ③ ④ ⑤ ⑦ ⑥

2.3 OUTDOOR UNIT (DOORBELL)

① ③ ② ④ ⑤

3. INSTALLATION

3.1 FIX THE MOUNTING PLATE OF THE INDOOR UNIT (MONITOR)

A+B

C

D 2x

E+F

3.2 FIX THE MOUNTING PLATE OF THE OUTDOOR UNIT (DOORBELL)

A+B

C

D 4x

E

F C

G

3.3 ELECTRICAL INSTALLATION

Indoor monitor

Outdoor camera

2 wire

2 wire

Door lock
(not included)

Power

Gate opener
(not included)

Power DC 15V

3.3.1 CONNECTING THE INDOOR UNIT (MONITOR) TO THE OUTDOOR UNIT (DOORBELL)

Power ① ＋

Gate opener
(not included)

Door lock
(not included)

Red

Black

3.3.2 CONNECTING THE AC ADAPTER

Power DC 15V

Indoor monitor

3.3.3 MOUNT THE INDOOR UNIT AND OUTDOOR UNIT

A

B

3.3.4 CONNECTING A GATE OPENER (NOT INCLUDED)

Power

Gate opener
(not included)

3.3.5 CONNECTING A DOOR LOCK (NOT INCLUDED)

Door lock
(not included)

4. BASIC FUNCTIONS

① ② ③ ④ ⑤ ⑥